



Shiodome City Center 1-5-2, Higashi-Shimbashi, Minato-ku, Tokyo 105-7117, Japan

Technical Literature I-11

Soldering Resistance of AURUM®

Test specimen: Small dumbbell specimens (thickness: 2 mm)

Testing method: After a specimen is immersed in a soldering bath for 10 and 30

Seconds, the change in the appearance was observed.

The purpose of drying: To check the effect of dehydration

1. 10-second Immersion in the Soldering Bath

Immersion	Drying	PPS	PES	AURUM	AURUM
temp., ℃		Natural	Natural	Natural	GF30% JGN3030
240	Yes	0	0	0	0
	No	0	0	0	0
260	Yes	0	0	0	0
	No	0	×	0	0
280	Yes	×	×	0	0
	No	×	×	0	×
300	Yes	×	×		0
	No	×	×	×	X

2. 30-second Immersion in the Soldering Bath

Immersion	Drying	PPS	PES	AURUM	AURUM
temp., ℃		Natural	Natural	Natural	GF30% JGN3030
240	Yes	0	\circ	\circ	0
	No	\circ	×	\circ	0
260	Yes	\circ	×	\circ	0
	No	×	×	\circ	0
280	Yes	×	×	0	0
	No	×	×	×	×
300	Yes	×	×	×	×
	No	×	×	×	X

O: No change in appearance

X: There was change or deformation.

The information contained herein is based on the information and data available at this moment, but none of the data or evaluation results contained herein provide any warranty whatsoever.